

Content

1 Device - Revision Record - What is new?..... 1

1.1 Hardware 1

1.2 Software..... 1

1.3 Device..... 1

2 DTM (Device Type Manager) 1

2.1 Supported devices 1

2.2 DTM (driver) Version record – What is new?..... 1

2.3 Requirements..... 2

2.3.1 PC-Hardware, Operating system 2

2.3.2 Frame application / compatibility 2

2.4 Installation and configuration..... 2

2.4.1 Installation..... 2

2.4.2 Uninstall instructions..... 2

2.5 Update- / Upgrade instructions 2

2.6 Known problems and limitations..... 2

2.7 Getting help / further information..... 2

2.8 How to get the latest information & software? 2

2.9 Licensing the DTM..... 2

3 EDD (Electronic Device Description)..... 2

3.1 Supported devices 2

3.2 EDD Version record – What is new? 2

3.3 Requirements..... 2

3.3.1 Interpreter / compatibility 2

3.4 Installation and configuration..... 2

3.5 Known problems and limitations..... 2

3.6 Getting help / further information..... 2

3.7 How to get the latest information & software? 2

*) DTM500 Bundle Supplement Info is available on the data medium \documentation or latest on www.abb.com/fieldbus. Enter here in the search field following No. "3KXD801500R3901".

1 Device - Revision Record - What is new?

1.1 Hardware

Released Revision	Released Date	Remarks
00.01.01	Dec. 2009	First release
00.01.02	Dec. 2012	Updated microP model

1.2 Software

Released Revision	Released Date	Remarks
07.01.12	Dec. 2009	First release
07.01.14	Dec. 2010	bugfixes
07.01.15	Dec. 2012	Input Pressure polarity selection
07.01.50	Feb. 2013	Changes to support new MicroP of hardware revision 0.1.2

1.3 Device

Released Revision	Released Date	Remarks
01	Dec. 2009	First release

2 DTM (Device Type Manager)

2.1 Supported devices

- 2600T Series Pressure Transmitters 266 PdP-HART
- Differential Pressure
- Gauge Pressure
- Absolute Pressure

2.2 DTM (driver) Version record – What is new?

Released driver Version	Released Date	Released bundle / Library Version	Remarks
05.00.00	Jan. 2010	≥ 05.01.00 / ≥ 05.00.15	First release Part of the DTM500 Bundle
05.00.01	May. 2011	≥ 05.03.00 / ≥ 05.00.17	- Moved "Soft write prot" under "Extras" - Introduced "Write num response preamble" under "Extras" - Improved user curve management - Improved Diagnosis management
05.00.02	July 2011	≥ 05.03.00 / ≥ 05.00.17	Bugfixes release for. - Device Serial Number not correctly displayed in Identify - Apply button not working in parameterize/display

05.00.03	July 2012	≥ 05.04.00 / ≥ 05.00.18	News: - new DTM library - Selection of Pressure polarity for some sensor types Bugfixes: - PILD parameter setting
05.00.04	July 2013	≥ 05.05.00 / ≥ 05.00.20	News: - New DTM library - Selection of HART Read Only Mode when used in Safety Critical Loop with Interface Safety Card AI880

- The device DTM supports the standard FDT 1.2 / 1.2.1.

2.3 Requirements

2.3.1 PC-Hardware, Operating system

See DTM500 Bundle Supplement Info*)

2.3.2 Frame application / compatibility

See DTM500 Bundle Supplement Info*)

2.4 Installation and configuration

2.4.1 Installation

See DTM500 Bundle Supplement Info*)

2.4.2 Uninstall instructions

See DTM500 Bundle Supplement Info*)

2.5 Update- / Upgrade instructions

See DTM500 Bundle Supplement Info*)

2.6 Known problems and limitations

Additionally to the common hints in the DTM500 Bundle Supplement Info*) attached the device driver specific hints.

- In some cases it's not possible correctly writes to the device the 'Linear Table with 22 points'. This depends on the 'Windows regions' and language setting of the DTM. This can be solved with a Windows regions setting of 'English (US)' and a language setting of the DTM also to 'English'.

2.7 Getting help / further information

- Press 'F1' for DTM online help.
Help concerning the integration of the DTM in the FDT frame application can be found in the respective documentation of the frame application.

2.8 How to get the latest information & software?

The latest device driver Supplement Info & software (driver) is available on www.abb.com/fieldbus:

- latest information [*field device protocol dependent*]
- latest info (download) [*device type dependent*]
 - Driver description
 - Software [*driver type dependent*]

2.9 Licensing the DTM

See DTM500 Bundle Supplement Info*)

3 EDD (Electronic Device Description)

3.1 Supported devices

3.2 EDD Version record – What is new?

Released Version	Released Date	Remarks
01 01	Feb 2010	First release
01 02	May. 2013	- introduced the Selection of Input Pressure polarity for some sensor types
01 03	Sept. 2013	Bugfixes: - device serial number interpretation - PV forced to 0.0 when PV unit is changed with Emerson AMS

3.3 Requirements

3.3.1 Interpreter / compatibility

Compatible with HHT375/475, PDM, AMS and any Software DD based.

3.4 Installation and configuration

Start your Frame application and follow the instructions.

3.5 Known problems and limitations

None known

3.6 Getting help / further information

- Help concerning the integration of the driver in the frame application can be found in the respective documentation of the frame application.

3.7 How to get the latest information & software?

The latest device driver Supplement Info & software (driver) is available on www.abb.com/fieldbus:

- latest information [*field device protocol dependent*]
- latest info (download) [*device type dependent*]
 - Driver description
 - Software [*driver type dependent*]

**ABB has Sales & Customer Support
expertise in over 100 countries worldwide.**

<http://www.abb.com/instrumentation>

The Company's policy is one of continuous product improvement and the right is reserved to modify the information contained herein without notice.

Printed in the Fed. Rep. of Germany (07.2013)

© ABB 2013



Germany

ABB Automation Products GmbH
Borsigstr. 2
63755 Alzenau

Tel: +49 (0)551 905-534
Fax: +49 (0)551 905-555
vertrieb.instrumentation@de.abb.com

USA

ABB Inc.
125 E. County Line Road
Warminster, PA
18974-4995

Tel: +1 (0)215 674 6000
Fax: +1 (0)215 674 7183
instrumentation@us.abb.com

Italy

ABB S.p.A.
Via Statale 113
22016 Lenno (CO)

Tel: +39 0344 58111
Fax: +39 0344 56278
abb.instrumentation@it.abb.com

UK

ABB Limited
Oldends Lane
Stonehouse
Gloucestershire GL10 3TA

Tel: +44 (0)1453 826 661
Fax: +44 (0)1453 829 671
instrumentation@gb.abb.com

P.R. China

ABB Engineering (Shanghai) Ltd.
32 Industrial Area
Kangqiao Town, Nanhui District
Shanghai, 201319

Tel: +86 (0) 21 6105 6666
Fax: +86 (0) 21 6105 6677
china.instrumentation@cn.abb.com